

CompactFloor® DIRECT 1.5



Installation



Lay a suitable pressure-resistant dry-construction floor heating and adhere the entire surface to the subsurface.



Subsequently, lay the pipe tension-free from above in a large arc according to the manufacturer's instructions.



Cut off the edge insulating strips flush with the floor heating prior to laying the CompactFloor DIRECT 1.5.



To lay the CompactFloor DIRECT 1.5 in a room, begin in a corner with the aluminium facing upwards.



Cut out the individual cutouts in the room using a cutter or carpet knife.



Lay the CompactFloor DIRECT 1.5 length for length tension-free. Joint edges should not overlap in the process.



Adhere all joint edges using CompactFloor DIRECT 1.5 aluminium adhesive tape for sealing and optimum heat transfer.



Tension-free and smoothly laid CompactFloor DIRECT 1.5 surface.



CompactFloor DIRECT 1.5 is directly accessible after laying. Lay the pre-finished parquet according to the manufacturer instructions as a floating installation.