

CompactFloor® EXPERT 20



Installation



Lay a suitable pressure-resistant dry construction floor heating and roll out an overlapping separating layer (film) onto it.



Add component B (2 kg) into component A (4 kg) and mix completely. Wear protective glasses and gloves.



Place the mixed epoxy adhesive into a clean bucket and re-mix. The processing time for the adhesive is approx. 90 minutes (at 23°C).



Apply the epoxy adhesive along the joint edge using a trowel and firmly press the next element against it. Min. joint width: 2 mm.



Begin with the remainder piece (≥ 20 cm) of the previous row and lay the elements with an offset (≥ 20 cm), avoiding cross joints.



Immediately remove any excess adhesive and use this for the next joint edge.



Measure the required cutouts in the room and cut individually to size. In the process, observe the necessary offset.



Cut the elements using a conventional diamond cutting disc without water cooling.



The CompactFloor EXPERT 20 is accessible and coverable after a 24-hour drying period. (Notice our material releases → Datasheets floor covering | adhesive).