

CompactFloor® PRO



Installation

! The skin formation time of the CompactFloor hybrid adhesive is approximately 4 minutes. After commencement of the skin formation, further sticking is no longer possible. Already applied adhesive has to be removed.



To start laying, saw off the projecting fold of the first element and do the same for the complete first row.



Start laying in the left-hand corner of the room. Do not press the edge insulating strips together as you do so.



Shorten the last element in a row to length (e.g. using a circular saw blade Diamaster or a jigsaw blade T141 HM, Bosch).



Start with the remainder piece (≥ 20 cm) so that you lay in subway bond (joint offset ≥ 20 cm). Apply two adhesive strings to the rebate (\varnothing approx. 5 mm).



Apply the first adhesive string close to the inside edge, and the second one in the last third of the rebate (approx. 5 m²/cartridge).



Place element onto the rebate, push it into the correct position. Skin formation time of the adhesive: approx. 4 min. Rebates have to be adehred during this time.



Press the element firmly down along the rebate. Some of the adhesive will be forced out of the joint.



Cut cutouts individually to size and adhere these into the rebate, too.



After a 24-hour drying period, the excess adhesive can be removed with a spatula. After that, the floor covering can be laid (Notice our material releases → Datasheets floor covering | adhesive).