

CompactFloor® THERM PU



Installation

For layer thicknesses up to 30 mm, use a PU primer.



Lay out the edge insulation strips, carefully clean the subsurface and prime for sufficient adhesion with the deep primer.



Add the entire contents of the granulate sack into a mortar bucket and add the entire tin of PU binder.



Carefully mix for 3 minutes in an agitator. For an improved mixing result, transfer into a second mortar bucket and re-mix for one minute.



Form dams based on the metre level in the height profile. Layer thickness at least 10 mm to max. 100 mm.



Fill up the area between the dams and densify by knocking them with a trowel.



Strip the surface, retaining the height profile.



During processing, regularly paint the tool with edible oil.



Then smooth the surface with a trowel. The processing time is 30 – 45 minutes.



After 3-4 hours' drying time, the surface can be walked on, and after 24 hours, it can be laid. Observe: CompactFloor THERM PU is not a finished usable layer on which floor coverings can be directly laid.